



Clara Apartments

Operating Instructions for the Bticino Video Intercom System



Entry Panel

Entrance Panel

To call an apartment from an entry panel
- dial the apartment number then the bell
key to call

Your visitors can call your apartment from a call panel located at the building entrance/s. When called, the system will transmit an electronic tone to your apartment video/audio intercom handset.

You may answer the call by lifting the handset. To grant your visitor/s access into the building, press the DOOR RELEASE BUTTON (button with key symbol). This function will unlock the entry door for approx 5 seconds. To grant your visitors access to your apartment level via the lift car/s press the lift release button. This function will de-secure the lift car/s floor select button for approx 90 seconds.



Lift Release Button

Door Release button

Video Monitor
344832

